


## Demonstration of exchanging a Turntable Control Panel

請打開旋轉控制器的門，斷開控制器與馬達軍規線，請旋轉後再拔開。  
Open up the door and unplug the connectors.




請拔開控制器電源線，再將控制器從門上取出。  
Unplug the power extension. Take out the panel.



換上新的控制器，請依以下步驟：

Replace with a new control panel as shown in the following steps:



正面顯示圖

Front view



請連接旋轉控制器與轉盤馬達之軍規接頭

The turn table motor needs to be reconnected to the new turntable control panel.



再將控制器的電源線接上即完成安裝維修。

Power the turntable control panel. Exchange is completed.